## Notes about the car.

- 1. The Battery Isolator Switch is Behind The Drivers Seat.
- 2.Car Supplied With Hydraulic Jack & Rubber Mallet To Remove, /Fit Wheels.
- 3. The Supercharger Oil Supply is Through a Drip Feed On Top of The Unit Just Behind The Drive Belts @ 1 Drip per Second, Adjustable By The Turn Knob on Top of The Glass Inspection Unit.
- 4. There is a Thermostat Fitted in the Top Hose, Pushed IN, which Is Best Removed In Warmer Weather.
- 5.Oil PSI is approx 80 Cold, 70 Hot.
- 6. Water Temp 60-70. This is the Best Running Temp, Hence The Radiator Half Blank Off.
- **7.**Standard Crash Gearbox, Double De Clutch, 2<sup>nd</sup> Helical Gears Always Noisy. Better When Oil is Warmed Up.
- 8. Use Only Gear Oil Through The Cars Own Lubrication System, NEVER TRY PUSHING GREASE THROUGH THE SMALL BORE PIPEWORK.
- 9. Engine Oil Filter Conversion Wix WL 7023.
- 10. Ignition Key No: MRN 24.
- 11. Car Paint: 2 Pack ,Jaguar Dark Blue. Code JGL Nexa / ICI
- 12. Car Supplied with Touch In Paint, Spare Oil Filter.
- 13. Suggested Best Manual to Purchase : The Complete MG Workshop & Tuning Manual, by W.E Blower.
- 14. Useful Tip when Fitting Hood: Fit top of windscreen first, then @ the back, Warm up if poss with haidryer, or in the sun.
- 15. Liftadots on Hood & Tonneau LIFT from the DOT side.
- 16. Current Engine Oil: Valvolene 20/50 Racing Oil. Gearbox & Differential 80/90 Gear Oil.